



Parts List for D55152 Type 1

Item Number	Part Number	Description	Qty Required
1	5137078-00	PUMP/MOTOR ASSY.	1
3	5130004-00	SCREW	8
4	5130010-00	NUT	4
5	5130019-01	SCREW	4
6	5130023-00	ELBOW	1
7	5135172-01	NAME PLATE	1
8	N003818	BALL VALVE	1
9	5134369-00	FOOT	4
10	5130546-00	TUBING	1
11	5130039-00	SLEEVE	2
12	5140030-78	CHECK VALVE ASSY	1
13	5130021-00	CONNECTOR	1
14	N008792	REGULATOR RPR KIT	1
14	A18912	MANIFOLD ASSY.	1
15	5130026-00	GAUGE	2
15	5130026-00	GAUGE	2
15	5130026-00	GAUGE	2
15	5130026-00	GAUGE	2
16	5137132-00	DECAL	1
17	5137077-02	PANEL	1
18	5131033-00	HOSE BARB	2
19	5136480-00	HOSE CLAMP	2
20	5136482-00	CAP,HOSE CLAMP	2
21	A13450	HOSE	1
22	5137076-00	PLUG	1
23	5136806-00	PLUG	1
24	5133478-01	FRAME	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for D55152 Type 1

Item Number	Part Number	Description	Qty Required
25	SSW-7367	BUSHING STRAIN RELIEF	2
25	438010040063	HEYCO BUSHINGS	1
25	438010040063	HEYCO BUSHINGS	1
26	5130046-00	CORD & PLUG	1
29	5130030-00	VALVE	1
30	5130028-01	PRESSURE SWITCH	1
31	619295-00	AFTERCOOLER	1
32	5130034-00	SLEEVE	2
33	5130035-00	NUT	2
36	5130062-00	DECAL	1
37	5130054-00	DECAL	1
39	5130059-00	DECAL	1
40	5130055-00	LABEL, WARNING	1
41	5130066-00	DECAL	1
42	5137140-00	DECAL	1
44	5132290-00	QK CPLR UNIV 3/8	2
45	5140028-29	BASE PLATE	1
46	619698-00	LABEL	1
47	A12446	SELF TAPPING SCREW	4
48	5130033-00	COLD START VALVE	1
50	5140023-85	REGULATOR RPR KIT	1
51	450213-00	TERMINAL, FEMALE	4
201	5130077-00	BOLT	4
203	5140016-71	CYLINDER HEAD	1
204	5140019-80	FILTER	1
205	5130078-00	GASKET	1
206	5140016-72	VALVE PLATE	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenetwork.com for current parts information.

Parts List for D55152 Type 1

Item Number	Part Number	Description	Qty Required
207	5140026-39	GASKET	1
208	5140016-73	VALVE BLADE	2
209	5140016-74	VALVE PLATE GASKET	1
210	5140016-95	CYLINDER	1
211	5130105-00	BOLT	2
212	5140016-75	SEAL	1
213	5130084-00	PISTON RING SET	1
214	5130085-00	PISTON	1
215	5130086-00	PIN	1
216	5130087-00	RETAINING RING	2
217	5130102-00	PISTON ASSY.	1
218	5130088-00	CONNECTING ROD	1
219	5140016-76	CONDENSER	1
220	5140016-77	COVER	1
222	5140016-78	DIPSTICK	1
223	5140016-79	SCREW	4
224	5140016-80	COVER,MOTOR	1
225	5140016-81	O-RING	1
226	5140016-82	SCREW	1
227	5140016-83	COVER,SEAL	1
228	5140040-44	CASE ASSY	1
229	5130101-00	NUT	2
230	5134583-00	CIRCUIT BREAKER	1
231	5140016-86	CRANKSHAFT	1
232	5140016-87	BEARING	1
233	5140016-88	SEAL	1
236	5134652-00	BEARING	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for D55152 Type 1

Item Number	Part Number	Description	Qty Required
237	5134707-00	END COVER	1
238	5140016-91	SCREW	2
239	5130107-00	FAN	1
240	5140016-92	HOUSING	1
241	5130097-00	SCREW	2
243	5140016-94	SEAL KIT	1
800	5130702-00	OIL	3

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.